Softlog Systems (2006) Ltd.

**Softlog
Systems**

1 Installing ICP2 and ICP2-GANG on USB Port

The following steps will show how to install the device under Windows XP. Basically, the procedure is also somewhat the same for other Windows operating systems.

1. Power on your PC and boot to Windows
2. Install ICP Family software from supplied CD or from www.softlog.com (file IcpWin_setup_x_xx.exe) to directory "C:\Program Files\Soft-Log\IcpWin"
3. Connect ICP2/ICP2-GANG to the PC with a USB cable. "POWER" LED on ICP2 may not work until device is not installed on USB port
4. Windows will detect the new device and will initiate the "Found New Hardware Wizard" prompting you to install the software for the detected USB device

5. Select "No, not this time". Click "Next" to continue

6. Select "Install from a list or specific location (Advanced)". Click "Next" to continue

ICP2 USB Driver Installation

7. Specify path to the driver: "C:\Program Files\Soft-Log\IcpWin\ICP2_USB_Driver". Click "Next" to continue

8. Click "Continue Anyway"

9. Click "Finish"

10. Windows will detect the new device again and will initiate the "Found New Hardware Wizard" prompting you to install the software for the detected USB device

11. Select "No, not this time". Click "Next" to continue

12. Select "Install from a list or specific location (Advanced)". Click "Next" to continue

13. Specify path to the driver: "C:\Program Files\Soft-Log\IcpWin\ICP2_USB_Driver". Click "Next" to continue

14. Click "Continue Anyway"

15. Click "Finish"

ICP2 USB Driver Installation

2   Verifying the Installation

This section will guide you on how to verify if the ICP2 USB was properly installed. You will also need to determine the COM port assignment made by Windows for the ICP2 USB port

To verify if the device is properly installed and determine the COM port assignment of the device:

1.   Click **Start** → **Settings** → **Control Panel** → **System**. Inside "System Properties" click "Hardware"

2.   Click "Device Manager"

3.   Double-click "Ports (COM & LPT)"

ICP2 USB Driver Installation

4. You should see "ICP2 USB to UART Bridge Controller (COMx)" in device listing. It also means that Windows has assigned the ICP2 to COMx

3 Uninstalling the Device

It's easy to uninstall the ICP2 USB driver

1. Click **Start** → **Settings** → **Control Panel**

2. Double-click "Add or Remove Programs"

3. Select "ICP2 USB to UART Bridge Controller" and click "Change/Remove"

4. Click "Yes"

5. Click "No"

6. Click "OK"